




# MOUNTING INSTRUCTION

## RFi SOFTBOX

### HOW TO MOUNT YOUR RFi SOFTBOX



1. Position the rounded rod end into the loops. Color markings on the rod end should be towards center.



2. Press the rod fully into the corner pocket. The rod should stay in the pocket even when disassembling the softbox.




3. Check the color of the dot on the rods of your softbox, e.g. if there's a blue dot you match it with the blue dots on your RFi Speedring.



4. Align the rods with the holes by slightly bending the rods. By slightly bending the opposite rod against your leg or the floor the tension on the softbox will decrease and mounting gets easier. Repeat the procedure when disassembling the softbox.



5. Tighten the softbox fabric with the Velcro to prevent light from leaking out.



6. Attach and stretch the inner diffuser with the Velcro attachment.



7. Tighten the diffuser all around to prevent leakage. Mount the outer diffuser close to the silver side and not to the softbox outer edge.

The softbox is now ready to use. Now mount it on your Profoto flash.

