






















































CONTROL PANEL



FUNCTION

Programming		
Power	 	Down / Up
Ready charge beep		On / Off
Test		Manual trigger
Photocell		On / Off
Eye cell pre-flash sensor	 Press 4s	On
Modelling lamp		prop/min/max/off/
Master reset	Press together   and turn on the unit	

SETTING

Programming			
Visual flash control Set Modelling Lamp to turn off during recharge	Enter into menu	Toggle sub-menu	
	Press 2s 		<div>Set with  </div> <div> On</div> <div> Off</div>
Proportional modelling lamp set up Set Modelling Lamp to 50% on 250ws Head for proportionality with 500ws Head			<div>Set with  </div> <div> On</div> <div> Off</div>
Charge ready beep set-up Set ready beep between 70-490 ms	Press 2s 		<div>Set with  </div> <div> V ^</div> <div> Between 70-490 ms</div>
Red eye pre-flash recognition	Press 4s 		<div>Set with  </div> <div> Auto count the flash</div> <div> No pre-flash</div> <div> 6 pre-flash</div>
EL-Skyport activation			<div>Set with  </div> <div> Off</div> <div> Normal mode</div> <div> Speed mode</div>
EL-Skyport group settings	Press together  		<div>Set with  </div> <div> V ^</div> <div> Group 1 to 4</div>
EL-Skyport frequency channel settings			<div>Set with  </div> <div> V ^</div> <div> Channel 1 to 8</div>
Power & modelling steps set-up Set power change to steps 1/10, 5/10 or up to 1/1 f-stop			<div>Set with  </div> <div> 1 stop</div> <div> 1/10</div> <div> 5/10</div>
Master reset	Switch off the unit than press together   and turn on again		

Changes are saved automatically after 4s

DECLARATION OF CONFORMITY USA AND CANADA

EN This device complies with Part 15 of the FCC Rules and with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This product complies with the Canadian ICES-003 Class B specifications.

FR Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes(1) ce dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Radiation Exposure Statement

EN This equipment complies with portable RF exposure limit in Canada and the USA set forth an uncontrolled environment and is safe for intended operation as described in this manual. Further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body.

FR Le produit est conforme aux limites d'exposition pour les appareils portables RF pour les Etats- Unis et le Canada établies pour un environnement non contrôlé. Le produit est sûr pour un fonctionnement tel que décrit dans ce manuel. La réduction aux expositions RF peut être augmentée si l'appareil peut être utilisé aussi loin que possible du corps de l'utilisateur.

FCC Class B Compliance note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device is limited to operation on permissible Part 15 frequencies, and is does not have the ability to be configured by end users or professional installers to operate outside the authorized bands.

Product name:	D-Lite RX 2 / D-Lite RX 4	Phone:	+41 21 637 26 77
Trade name:	ELINCHROM	Fax:	+41 21 637 26 81
Model number(s):	20486.1 / 20487.1	Email:	elinchrom@elinchrom.ch
Name of responsible party:	Elinchrom LTD Av. de Longemalle 11 1020 Renens / Switzerland		

TROUBLESHOOTING

E1	Overvoltage detected	Switch unit OFF, wait 2 minutes and switch unit ON again. If the error shows up again the unit requires a check up at the Elinchrom service centre
E2	Overheating	Wait until the unit has cooled down. The unit will switch back to normal operation as soon as temperature decreases to normal working level.
E3	Auto dump function fault	The Unit has detected a time out in the ADF mode. Switch the unit OFF, wait 2 minutes and switch the unit ON again; use the Test release button for power reduction. If the error shows up again the unit requires a check up at the Elinchrom service centre.
E4	Charge fault	Unit has detected a time out during recharging. Switch unit OFF, wait 2 minutes and switch unit ON again. If the error shows up again the unit requires a check up at the Elinchrom service centre.
E5	Mains supply fault	Unit has detected a mains supply fault. Check your mains cord and mains installation sockets. Switch unit OFF, wait 2 minutes and switch unit ON again. If the error shows up again the unit requires a check up at the Elinchrom service centre.
E8	Fan manage-ment fault	Unit has detected a FAN management problem due to overheating. Wait until the unit has cooled down. Check if the FAN is blocked. If the error shows up again the unit requires a check up at the Elinchrom service centre.

DOWNLOAD THE USER GUIDE

Obtain the complete user guide using this link:

<http://bc.gs/um>

DOWNLOAD CONFORMITY

Find your declaration for EC and USA & Canada conformity here:

<http://bc.gs/ec>



is a registered trademark of ELINCHROM LTD, RENENS, SWITZERLAND

Quick Start Guide



Please check all security documents before use !

No guarantee for misprints - Elinchrom LTD
Av. de Longemalle 11, P. O. Box -458, CH-1020 Renens, Switzerland,
Tel. : + 41 21 637 26 77 Fax: +41 21 637 26 81 E-mail: elinchrom@elinchrom.ch
www.elinchrom.com